

SERIE SS-ZDG

High Speed Gauze Swab Folding Machine (un-folded edge)



Series high speed gauze swab folding machine can meet most of the standard gauze swab folding methods, such like folded edge or un-folded edge, 5x5cm, 7.5x7.5, 10x10cm, 8ply, 12ply, 16ply.

Copyright by LOYAL. This brochure contains photos and technical data for information only, without contractual engagement. LOYAL reserves the right to introduce any modifications in the design and/or equipment.





SERIE SS-ZDG

High Speed Gauze Swab Folding Machine (un-folded edge)

TECHNICAL SPECIFICATIONS



Humidification system makes the gauze swab folding in very good shape.

Electronic sensors monitor the output, give alarm to user if there is any folding mistake been happen, ensure accurate counting.





The gauze material roll tension controlled by magnetic powder clutch, machine running with stable tension.

Copyright by LOYAL. This brochure contains photos and technical data for information only, without contractual engagement. LOYAL reserves the right to introduce any modifications in the design and/or equipment.





SERIE SS-ZDG

High Speed Gauze Swab Folding Machine (un-folded edge)



Via simple adjustment, different tier (4ply, 8ply, 12ply and 16ply) can be done in ONE machine.

Technical Parameter	
Folding speed	290-400 pieces/min
Output tracks	2 lanes
Main power	6-10KW
Heating power	2.8KW
Compressor air	0.6Mpa

Copyright by LOYAL. This brochure contains photos and technical data for information only, without contractual engagement. LOYAL reserves the right to introduce any modifications in the design and/or equipment.



WUHAN LOYAL MACHINERY CO., LTD